

# SERVICE MANUAL

RADIO CASSETTE RECORDER

• BASIC TAPE MECHANISM: TN-21ZVC-1145

This Service Manual is the "Revision Publishing" and replaces "Simple Manual" (S/M Code No.09-997-333-6T2).





#### **SPECIFICATIONS**

General

**Tuner section** Frequency range:

FM: 87.5 - 108.0 MHz

MW: 530 - 1,605 kHz

LW: 150 - 285 kHz

FM: Rod antenna

MW, LW: Ferrite bar antenna

Speaker 90 mm cone type (1)

Output Earphone jack (monaural mini-jack)

Power output 1.7 W (DIN MUSIC POWER)

1 W (EIAJ 4 ohms, T.H.D. 10%) 0.8 W (DIN 1% Rated Power)

Power requirements DC 6 V using four size C (R14) batteries

AC 230 V,50 Hz

Power consumption 6 W

279 (W) x 128 (H) x 101 (D) mm **Dimensions** 

Weight 1.2 kg (excluding batteries)

**Deck section** 

Antenna:

Track format 2 tracks, 1 channel

Frequency range Normal tape: 50 - 10,000 Hz (EIAJ)

Recording system AC bias Erasing system Magnet erase

Heads Recording playback head (1)

Erasure head (1)

• Design and specifications are subject to change without notice.

#### **ACCESSORIES LIST**

DESCRIPTIONで判断できない物は "REFERENCE NAME LIST" を参照してください。 If can't understand for Description please kindly refer to "REFERENCE NAME LIST".

REF. NO

PART NO.

KANRI NO.

DESCRIPTION

1 8Z-CM2-908-010

IB,EZ(9L)A

2 87-A80-081-010

AC CORD SET ASSY, EZ BLK

# **ELECTRICAL MAIN PARTS LIST**

DESCRIPTIONで判断できない物は "REFERENCE NAME LIST" を参照してください。 If can't understand for Description please kindly refer to "REFERENCE NAME LIST".

REF. NO	PART NO.	KANRI NO.	DESCRIPTION	REF. NO	PART NO.	KANRI DESCRIPTION NO.
IC .	88-CM2-608-01 8Z-CM2-646-01		7628 HP 2132P	C239 C240 C301 C302 C303	87-A10-411-010 87-A10-176-010 87-A10-577-010 87-A10-577-010 87-010-236-080	O CAP,CER 1000P-50 M D O CAP,CER 0.022-50 Z YF O CAP,CER 0.022-50 Z YF
TRANSISTO	R 87-CD7-603-08 89-319-233-01		8050 C1923(O)	C304 C305 C306 C307 C308	87-A10-411-010 87-010-221-080 87-010-221-080 87-A10-411-010 87-010-248-080	O CAP, ELECT 470-10V O CAP, ELECT 470-10V O CAP,CER 0.047-16 K SR
DIODE	87-A40-246-08 87-A40-357-08 86-CM3-601-08 87-017-088-08	0 ZENER 0 DIODE 0 ZENER	,IN4148 T-72 ,3.9V ,CDG-24 ,4.7V	C309 C311 CF101 CF102 CF103	87-A10-211-010 87-010-248-080 8Z-CM1-642-010 82-785-747-080 87-008-554-010	O CAP, ELECT 220-10V O FLTR,SFU465B O FILTER, SFE10.7MS2-A O FLTR,CF CDA10.7MG60-A
	8Z-CM1-657-01 8Z-CM1-656-01		, IN60P , 1N4001B	CF104 D104 J1 L101 L102	82-785-747-080 87-CD8-614-010 8Z-CM1-608-010 8Z-CM2-669-010 8Z-CM2-661-010	0 VARI-CAP,1S2638 0 JACK, EP ZCM-1 0 COIL,FM RF4T4.5MM
C100 C104 C106 C110 C113	87-A10-176-01 87-A10-577-01 87-A10-162-01 87-A10-496-01 87-A10-176-01	0 CAP,C 0 CAP,C 0 CAP,C	ER 1000P-50 M D ER 0.022-50 Z YF ER 68P-50 KSL ER 18P-50 J CH ER 100P-50 M D	L103 L104 L105 L107 L201	8Z-CM2-660-010 87-003-143-080 8Z-CM2-668-010 8Z-CM2-642-010 87-003-149-080	O COIL,4.7UH COIL,BAR ANTLW COIL,BAR ANTMW
C114 C115 C117 C118 C121	87-010-404-08 87-A10-166-01 87-A10-171-01 87-A11-848-08 87-010-404-08	0 CAP, 0 CAP,C 0 CAP,C 0 CAP,C	ELECT 4.7-50V ER 150P-50 K B ER 390P-50 K B ER 24P-50V ELECT 4.7-50V	L301 <u>↑</u> PR301 PVC2 R306 SW101	87-003-149-080 87-A91-703-080 8Z-CM1-636-010 87-A00-436-050 8Z-CM2-649-010	FUSE PROTECTOR,800MA/60V TUN-CAP, EZ RES,100-1/2W J RP
C122 C124 C126 C128 C131	87-A10-182-01 87-010-400-08 87-010-402-08 87-010-405-08 87-A10-413-01	0 CAP, 0 CAP, 0 CAP,	ER 0.01-50 Z F ELECT 0.47-50V ELECT 2.2-50V ELECT 10-50V ER 2200P-4K M E KX	SW201 SW202 SW203 T101 T103	8Z-CM2-647-010 8Z-CM2-650-010 8Z-CM2-648-010 8Z-CM2-667-010 8Z-CM2-638-010	0 SW,PUSH 2-6-2 REC 0 SW,SL 2-2-2 BEAT 0 COIL,LWOSC
C132 C133 C134 C135 C202	87-A10-182-01 87-010-221-08 87-A10-411-01 87-A10-176-01 87-010-404-08	0 CAP, 0 CAP,C 0 CAP,C	ER 0.01-50 Z F ELECT 470-10V ER 0.047-16 K SR ER 1000P-50 M D ELECT 4.7-50V	T104 T201 TC101 TC102 VR201	8Z-CM2-637-010 8Z-CM1-605-010 87-A91-657-010 87-A91-657-010 8Z-CM1-603-010	O COIL, BIAS O TRIMMMER 20P O TRIMMMER 20P O VR,RTRY 50K A MAIN
C203 C204 C206 C207 C209	8Z-CM1-620-01 8Z-CM1-620-01 87-010-544-08 87-010-380-08 87-010-221-08	0 CAP,C 0 CAP, 0 CAP,	ER 500P-50 ER 500P-50 ELECT 0.1-50V ELECT 47-16V ELECT 470-10V	VR202 LED C.B D303	8Z-CM1-604-010 87-A91-052-080	
C211 C212 C213 C216 C217	87-010-221-08 87-010-400-08 87-010-380-08 87-A10-170-01 87-010-405-08	0 CAP, 0 CAP, 0 CAP,C	ELECT 470-10V ELECT 0.47-50V ELECT 47-16V ER 330P-50 K B ELECT 10-50V			
C218 C219 C220 C221 C222	8Z-CM1-620-01 87-A10-182-01 87-010-380-08 87-A10-182-01 87-A10-182-01	0 CAP,C 0 CAP, 0 CAP,C	ER 500P-50 ER 0.01-50 Z F ELECT 47-16V ER 0.01-50 Z F ER 0.01-50 Z F			
C223 C224 C225 C226 C227	87-010-401-08 8Z-CM1-620-01 87-010-405-08 87-010-263-08 87-010-545-01	0 CAP, C 0 CAP, 0 CAP,	ELECT 1-50V ER 500P-50 ELECT 10-50V ELECT 100-10V ELECT 0.22-50V			
C228 C229 C230 C232 C234	87-A10-840-01 8Z-CM1-620-01 87-010-402-08 87-010-221-08 87-010-380-08	0 CAP, C 0 CAP, 0 CAP,	ER 220P-1K K R LONG ER 500P-50 ELECT 2.2-50V ELECT 470-10V ELECT 47-16V			
C235 C236 C237 C238	87-A10-211-01 87-A10-182-01 87-010-544-08 87-010-248-08	0 CAP,C 0 CAP,	ER 0.1-50 M ER 0.01-50 Z F ELECT 0.1-50V ELECT 220-10V			


#### TRANSISTOR ILLUSTRATION




2SC1923 SS8050


# IC BLOCK DIAGRAM


IC, TA2132P




#### IC, TA7628HP









<tuner section=""></tuner>
1. FM Freq. Range Adjustment
L103 87.4 MHz
TC1
2. FM Tracking Adjustment
L102 88 MHz
TC2
100 1112
3. AM IF Adjustment
T104
1101
4. MW Freq. Range Adjustment
T103515 kHz
TC3
1035 KHZ
5. MW Tracking Adjustment
5. MW Tracking Adjustment
L107600 kHz
L107
L107 600 kHz TC4 1400 kHz  6. LW Freq. Range Adjustment T101 145 kHz TC101 295 kHz  7. LW Tracking Adjustment L105 150 kHz TC102 280 kHz
L107
L107 600 kHz TC4 1400 kHz  6. LW Freq. Range Adjustment T101 145 kHz TC101 295 kHz  7. LW Tracking Adjustment L105 150 kHz TC102 280 kHz

#### PRACTICAL SERVICE FIGURE

#### <TUNER SECTION>

Sensitivity:

FM (IHF, THD 3%) Less than 22 dB (at 88, 98, 108 MHz)

MW (S/N 10 dB) Less than 52 dB

(at 600, 1,000, 1,400 kHz)

LW (S/N 10 dB) Less than 65 dB

(at 150, 200, 280 kHz)

Intermediate Frequency: FM 10.7 MHz

AM 465 kHz

#### <TAPE SECTION>

Distortion: Less than 3.0% (PB) S/N Ratio: More than 35 dB Less than 30 mV (VR Max.) Noise Level:


Less than 2 mV (VR Min.)

3000 Hz + 90% - 60%

Tape Speed: Take up Torque 30 - 60 g-cm

FF/Rew Torque 45 - 140 g-cm FF/Rew Time 100 - 170 sec

Less than 0.4% (RMS) Wow & Flutter:




#### MECHANICAL MAIN PARTS LIST

DESCRIPTIONで判断できない物は "REFERENCE NAME LIST" を参照してください。 If can't understand for Description please kindly refer to "REFERENCE NAME LIST".

REF. NO	PART NO. KAN		REF. NO		NRI DESCRIPTION O.
2 3 4	8Z-CM2-024-010 8Z-CM2-009-010 8Z-CM2-027-010 8Z-CM2-063-010 86-CM2-212-010	COVER, CASS EX HLDR,CASS WINDOW,TUNING EZ CABI,FR EX ASSY (S) SPR-T,CASS	27 28 29	8Z-CM2-605-010 8Z-CM2-023-010 8Z-CM2-032-010 88-CS8-625-010 8Z-CM2-003-010	PT,E ZCM-2 CABI,REAR EZ KNOB,SL BEAT MIC,ECM KNOB,SL FUNCTION
7	8Z-CM2-208-010 8Z-CM2-209-010 8Z-CM2-006-010 8Z-CM2-205-010 8Z-CM2-607-010	GEAR, CASS HLDR, GEAR CASS POINTER, COVER, POINTER SPKR, F 4 40HM	32 33 34	8Z-CM2-005-010 8Z-CM2-608-010 85-CM1-211-010 8Z-CM2-206-010 85-CM1-212-010	KNOB,RTRY VOLUME ANT,ROD FM ZCM-2 SPR,BATT(-) SPR,BATT (+) SPR,BATT(+/-)
12 13 14	8Z-CM2-007-010 8Z-CM2-016-010 8Z-CM2-015-010 8Z-CM2-014-010 8Z-CM2-013-010	KNOB,RTRY TUNING KEY,CASS REC KEY,CASS PLAY KEY,CASS REW KEY,CASS FF	37 38 A	8Z-CM2-038-010 8Z-CM2-037-010 8Z-CM2-036-010 87-741-095-410 87-751-074-410	LID,BATT EX COVER, HANDLE EX HANDL,EX UT2+3-8 GLD VT2+2.6-8 W/0 CUT
17 18 19	8Z-CM2-012-010 8Z-CM2-011-010 8Z-CM2-207-010 8Z-CM2-201-010 8Z-CM2-204-010	KEY,CASS STOP KEY,CASS PAUSE PLATE,REC GEAR,TUNING HLDR,BAND	D	87-261-073-410 87-741-100-410 87-651-096-410	V+2.6-6 UT2+3-16(W/O) SLOT SCEW,ST3-10
22 23 24	8Z-CM2-640-010 8Z-CM2-202-010 8Z-CM2-203-010 87-A90-086-010 87-A60-178-010	BAR-ANT, AM HLDR, BAR-ANT BLIND, CASS COVER, AC-SOCKET JACK, AC E W/SW			

# COLOR NAME TABLE

Basic color symbol	Color	Basic color symbol	Color	Basic color symbol	Color
В	Black	С	Cream	D	Orange
G	Green	Н	Gray	L	Blue
LT	Transparent Blue	N	Gold	Р	Pink
R	Red	S	Silver	ST	Titan Silver
Т	Brown	V	Violet	W	White
WT	Transparent White	Y	Yellow	YT	Transparent Yellow
LM	Metallic Blue	LL	Light Blue	GT	Transparent Green
LD	Dark Blue	DT	Transparent Orange		



# TAPE MECHANISM PARTS LIST 1/1

DESCRIPTIONで判断できない物は "REFERENCE NAME LIST" を参照してください。 If can't understand for Description please kindly refer to "REFERENCE NAME LIST".

REF. NO	PART NO.	KANRI NO.		REF. NO	PART NO.	KANRI NO.	DESCRIPTION
1	S1-921-030-04	0	HEAD BASE AZIMUTH SPRING PANEL P SPRING GEAR PLATE SPRING GEAR PLATE ASSY	36	S1-821-100-98	0	PACK SPRING
	S1-821-030-07		AZIMUTH SPRING	37	S1-921-015-01		CHASSIS ASSY
			PANEL P SPRING	3.0	S1-921-140-21		REC BUTTON LEVER SPRING
4	91_921_950_05	n	GEAR PLATE SPRING	30	S1-921-073-02		RF CLUTCH ASSY
	S1-921-265-02		GEAR PLATE ASSY	40	S1-921-070-03		RF BELT
5	31-921-203-02	U	GEAR PLATE ASSI	40	31-921-070-03	U	Kr DELI
6	S1-921-140-37	0	P ARM COLLER P ARM HEAD PANEL BASE ASSY M CONTROL SPRING	41	S1-921-260-02	0	CAM GEAR
7	S1-921-140-34	0	P ARM	42	S1-921-140-16	0	E ACTUATOR SPRING
8	S1-921-030-01	0	HEAD PANEL	43	S1-921-093-03	0	FLYWHEEL ASSY
9	S1-921-143-01	0	BASE ASSY	44	S1-921-090-04	0	MAIN BELT
10	S1-921-140-18	0	M CONTROL SPRING	45	S1-820-130-06	0	MOTOR RUBBER
	S1-921-260-4A		SENSING LEVER PINCH ROLLER ARM ASY EJECT SLIDE LEVER P CONTROL SPRING PAUSE LEVER	46	S1-921-120-01		MOTOR PULLEY
12	S1-921-043-01	0	PINCH ROLLER ARM ASY	47	S1-921-030-05	0	MG ARM
13	S1-921-130-01	0	EJECT SLIDE LEVER	48	S1-921-030-10	0	MG ARM SPRING
14	S1-921-140-13	0	P CONTROL SPRING	49	S6-401-011-49	0	LEAF SW MSW-1541T
15	S1-921-140-10	0	PAUSE LEVER	50	S1-010-260-80	0	MOTOR EG530AD-6B
16	S1-921-140-12	0	PAUSE LEVER SPRING	A	S9-179-000-00	0	C TAP SCREW M2-3
	S1-921-140-11		PAUSE STOPPER	В	S1-821-120-02	0	MOTOR COLLER SCREW
18	S1-921-140-15	0	BUTTON LEVER SPRING(B)	C	S9-679-000-00	0	P TAP SCREW M2-5
19	S1-821-011-59	0	E KICK LEVER	D	S9-999-180-09	0	TAPPING SCREW(CAMERA)M2-4.5
20	S1-921-140-14	0	PAUSE LEVER SPRING PAUSE STOPPER BUTTON LEVER SPRING(B) E KICK LEVER BUTTON LEVER SPRING(A)	E	S9-004-000-00	0	SCREW M2-6
21	S1-921-140-20	0	PR STOPPER	F	S9-115-000-00	0	+ BIND SCREW M2-3
22	S1-921-140-09	0	SWITCH ACTUATOR	G	S9-922-000-00	0	AZIMUTH SCREW M2-8
23	S1-921-140-08	0	PUSH BUTTON ACTUATOR	H	S9-P05-200-61	0	SCREW, TAP S M 2-6
24	S1-921-140-03	0	REC BUTTON LEVER	Ī	S9-422-000-00	0	P WASHER CUT 1.2-3.8-0.3
25	S1-921-140-19	0	PR STOPPER SWITCH ACTUATOR PUSH BUTTON ACTUATOR REC BUTTON LEVER PLAY BUTTON LEVER	J	S9-999-030-13	0	P WASHER CUT 1.45-3.8-0.5
26	S1-921-140-04	0	REW BUTTON LEVER	K	S9-786-000-00	0	P WASHER 2-3.5-0.3
27	S1-921-140-05	0	FF, BUTTON REVER	L	S9-999-000-03	0	P WASHER2.1-4-0.13
28	S1-921-140-06	0	STOP BUTTON LEVER	M	S9-999-200-41	0	P TAP SCREW M2-3
29	S1-921-140-07	0	PAUSE BUTTON LEVER	N	S9-180-000-00	0	C TAP SCREW M2-4
30	S1-829-100-10	0	BACK TENSION SPRING				
31	S1-921-053-02	0	SUPPLY REEL ASSY				
32	S1-821-100-69	0	RECORD SAFETY LEVER				
33	S1-821-100-70	0	FF GEAR				
34	S1-921-050-06	0	SENSOR				
	S1-921-053-01		TAKE UP REEL ASSY				
33		-					

<u></u>					
サービス技術ニュース					
番号	連絡内容				
G					
G					
G					

アイワ株式会社 〒110 東京都台東区池之端1-2-11 ☎03(3827)3111(代表) **AIWA CO.,LTD.** 2-11, IKENOHATA 1-CHOME, TAITO-KU, TOKYO 110, JAPAN TEL:03 (3827) 3111

931196 Printed in Singapore